



Agile


Winder 2 column installation guide




Parts




1 x Left & Right Leg Pair




2 x Foot




2 x Leg Rail




1 x Cross Rail




1 x Drive Shaft




1 x L&R Support Bar Pair



1 x Winder



4 x Leveling Foot



8 x M8x25



8 x M8x10



6 x ST5.0x23



2 x M8x10



2x Washer



2 x ST3.9x12

Step 1




4 x M8x10



2 x M8x10





2 x Washer




Step 2





4 x M8x10





Step 3




4 x Leveling Foot



8 x M8x25




Step 4




Worktop	Length
1200mm	1125mm
1500mm	1425mm
1800mm	1725mm
2100mm	2025mm

Step 5




1 x Drive Shaft




Step 6




6 x ST5.0x23




Step 7a



1 x Winder




2 x ST3.9x12



FOR DEEP WORKTOPS REF PG-10 FOR POSITIONING DETAILS


Step 7b




Step 7c



2 x ST.3.9x12




Completed




Changing crank handle from right to left operation

Step 1




Changing crank handle from right to left operation


Step 2




Step 1




Step 2




Step 3




Step 4




Step 5



Step 6




Step 1




1 x Power/Data Plate



3 x Screw + Bolt



Complete



Directions for use

IMPORTANT!

Please carefully read the assembly manual and direction for use prior to installment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

SAFETY

- The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- Do not use the table frame to lift people.
- Please retain this operation manual and pass it on to any future owner.

USAGE

- The height-adjustable table is designed for use in dry work environments only.
- The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- The table has been designed as a device to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- CHILDREN should only use the table when supervised by adults.
- Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

SET UP AND INSTALLATION

- Assemble the table frame according to the assembly instructions
- Place the table in a safe distance from window frames, radiators, furniture etc. So that persons cannot become trapped.
- Level the table with the adjustable feet ensuring that the table is stable.
- Check that no cables can get jammed.

MAINTENANCE

- The table does not require any maintenance by the user
- The table is only to be cleaned with a wrung cloth.

TECHNICAL DATA

Height Range: 680-1130mm