

## *Metro-Visitor Assembly Instructions*

1. Open carton and unpack all components
2. Place seat/backrest assembly **A** upside down on a bench/table
3. Locate 2 inserts on either side of seat/back frame, and fit arm rests **B** using 4 machine screws provided

