

## Metro Midback Assembly Instructions

1. Open carton and unpack all components
2. Turn chair base **A** upside down and insert castors **B** into the holes provided, pressing down firmly on castors to ensure a secure fit
3. Turn chair base **A** right side up and insert gas lift cylinder **C** into large hole through chair base
4. Carefully place seat/backrest assembly **D** onto gas lift cylinder **C**, fitting cylinder into hole in bottom of control mechanism. Press down firmly to ensure a secure fit.

